

Floor scale for Medical use User Manual

MBPB-250






www.liden-weighing.com

SPECIFICATION

Modell	MBPB-250
Max kapacity	250 kg
Readabillity	100 g (0,1 Kg)
Accuracy	OIML Klass III
Tara	100 %
Min. loading	2 kg


Specification	
Display	25 mm heigh, 5 segment, LCD-display
	with background light
Construction	Steel pipe construction
Product size	320 x 5000 x 1070 mm
Platforme size	320 x 375mm
Stabilization time,	3 Second standard
approx	
Operating temerature	0°C - 40°C / 32°F - 104°F
Power supply	7,5V/1A AC adapter and 6xAA Battery
EU-verified in	
accordance with	Klass III
2014/31 / EU	
MDD approved in	
accordance with	Klass I
93/42/EEC	

Keypad



Keypad funtion





[→T←] Tare key

Hold key

Recall last data

BMI BMI

Symbols



NET Net display / Scale is tared in position

Recalled value

HOLD Lock (hold) mode

o Stable mode on

Operation & Key functions

On/Off
Press briefly to switch the scale on and off.

Recet button
Resets the scale display. Used for unloaded scales.

>0

indicated.

→T← Tare key

The tare button is used to tare things that are weighed together with the patient (eg clothes, shoes or other). Do this: place a weight (clothes, shoes or other) on the scale. Press to remove this weight. The display will show NET.

Remove (clothes, shoes or other) and press to exit tare function.

Manual or automatic hold function
In zero mode, you can use the manual or automatic hold function by pressing HOLD the display shows **Hold Auto** eller **Hold Off**.

Manual hold: Stand on the scale. Wait for the stable value, then press

to lock the value.

The display returns to <u>zero</u> after about one second. The value is

retrieved by pressing Cancel. **Automatic Hold**: Set Hold Auto as above by pressing Stand on the scale. At stable weight, the scale will automatically lock the value. If the weight after locking changes more than 4 kg, the scale is activated again

and, when the scale is stable, will again automatically lock the value.


BMI


BMI - Body Mass Index

- 1. Put a person on the scales and wait until the scales are stable.
- 2. Press again on to exit and view the calculated BMI.
- 3. The BMI value disappears when the person leaves the scale but can be recalled with

Replacing batteries:

- 1. Disconnect the power supply to the scale.
- 2. Remove the battery cover on the back of the indicator. Insert 6 pcs. new AA batteries and make sure the poles are seated correctly.
- 4. Close the battery cover.





NOTE! Do **not** use rechargeable batteries. If you do, the batteries should be charged in an external charger. The scale adapter cannot charge the batteries when they are in the scale.

Assembling:


1. Take out the load cell signal cable.




2. Load cell signal cable go through the column.




3. Screw the column tightly as below.



4. Load cell signal cable go through the indicator holder.



5. Connect indicator cable and fasten the fixed knob.



Cleaning.

Cleaning / Disinfection

During all maintenance work with the chair scale, the power supply must be cut off.

The chair with seat and backrest may only be cleaned with household cleaners or disinfectants, e.g. 70% isopropanol solution.

We recommend a disinfectant that is intended for disinfection by wet drying the surfaces of the chair scale.

There, follow the manufacturer's instructions.

Do not use polishes or aggressive cleaners such as alcohol, gasoline or anything else, as they can damage the surfaces that are made of plastic or rubber.